CM HEADEND

CM KEY





REMOTE MANAGEMENT KEY LICENSE TO ACCESS CM HEADEND INSTALLATIONS


- ✓ The CM KEY allows remote connection to the FA 524 power supply through the CM Management program (Software that allows to manage CM headend on-site by USB cable or remotely via LAN cable). The CM KEY is specific for each FA 524 power supply.
- ✓ From a FA 524 power supply connected to the internet, you can remotly access all modules in the CM headend.
- Additionally, a user key and password are provided to identify your company in our remote server.
 With this key and password you can access and remotely manage all your existing installations.
- ✓ Multiple users can access your installations using the same credentials but only 1 user can connect to a CM Headend at a time.






CM KEY

Remote management key



CM KEY





T CM Key

ITS Partner O.B.S S.L · Av. Cerdanyola 79-81 Local C 08172 Sant Cugat del Vallés · Barcelona (Spain) Phone: +34935839543 · info@ek.plus · www.ek.plus